



DNV-GL



Application

- Used for both seaman and passengers.



0098

Standard

- SOLAS 74 as amended Reg. III/4, III/7, III/22, III/34 and X/3, 1994 and 2000 HSC Code 8, IMO Res. MSC.48(66) (LSA Code) I, II, IMO Res. MSC.81(70)

Approval (MED/DNV-GL)

- EC Certificate Module B No. 14988 - 15 HH
- EC Certificate Module D No. 11570 - 14 HH

Introduction of Product.

- **References**
An inherently buoyant lifejacket for adults approved for persons of over 43Kg up to 140Kg & Chest Girth up to 1750mm & height 155cm or over
Buoyancy: ≥ 150 N
Reflective tape: ≥ 400 cm²
Weight: ≤ 0.8 Kg
- **Fittings**
A piece of anti-corrosion whistle

Attention:

- HZ-AJ-II type lifejackets must be fitted with a lifejacket light which is EC approved while being used.

Wearing method

Used for both seaman and passengers.

DONNING METHOD FOR ADULT LIFEJACKETS



1. Unpack the lifejacket;
2. Unfasten buckles and loose the walstbelt;
3. put the waistbelt to your back and put the lifejacket over your head;
4. Fasten the buckles and tighten the waistbelt;
5. Position to jump into the water.

Use, maintenance

1. Always stow the lifejacket in a dry and well-ventilated place. Don't put it at high temperature or under the hot sun for a long time. Put it away from chemicals such as acid, alkali and salt to prevent from damage.
2. Don't squeeze the suit in order to prevent the deformation influencing its performance.
3. Store it after fully drying the lifejacket. Clean it with neutral cleaning agent and soft brush if any oil on the surface and then store it after drying it fully.
4. Examine it periodically to avoid the damage of the fabric, waist belt, buckle and other accessories resulting in a bad performance because of rain or sea penetrating into the lifejacket cabinet.

Distributor: